



BNZ Office



Gebruiksaanwijzing
Bedienungsanleitung
Operating instructions
Mode d'emploi
Instrucciones de uso

Zithoogteverstelling
Sitzhöhenverstellung
Seat height adjustment
Réglage de la hauteur d'assise
Regulación de altura del asiento



Synchroonmechaniek rugleuning

Synchronmechanik

Synchronous mechanism

Mécanisme synchrone

Mecanismo sincronizado



Zitdiepteverstelling
Sitztiefenverstellung
Seat depth adjustment
Réglage de la profondeur d'assise
Regulación de la profundidad del asiento



Gewichtsregeling
Gewichtsregulierung
Weight adjustment
Réglage de tension
Regulación de peso



Turn



Lendensteun
Lordosenstütze
Lumbar support
Soutien lombaire
Apoyo lumbar

Push



Hoogteverstelling van de armleggers
Höhenverstellung der Armlehnen
Height adjustable armrests
Accoudoirs réglables en hauteur
Regulación de la altura de los brazos



Breedteverstelling van de armleggers
Breitenverstellung der Armlehnen
Width adjustable armrests
Accoudoirs réglables en largeur
Regulación del ancho de los brazos



Verstellen armleggeropdek
Tiefenverstellung der Armauflage
Adjustable arm supports
Avant-bras réglable
Superficie de apoyo de los
brazos regulable en profundidad



